
-15V
minus 15 volt psu
200 volt psu
not used in PR1551
Extract from service manual
Power Supply PR1553
modified to show PR1551 version
OFF
STANDBY
GANGED
FS1 1A
FS2 2·5A 22V
A LINE
A NEUTRAL
EARTH
plus 5 volt psu
plus 12 volt psu
+12V
+5V