

	SWITCH NO.	CHANGE OVER CONTACT	H.F. CONTACT	L.F. CONTACT
FRONT SECTION	S1J	2	3	4
	S1F	5	6	7
	S1E	8	9	10
MIDDLE SECTION	S1D	8	9	10
	S1H	11	12	1
REAR SECTION	S1B	2	3	4
	S1G	8	9	10
	S1A	11	12	1

R109 Receiver